

# emoving The Trigger Mechanism And The Magazine

Use a bullet tip or a pin punch to strike the trigger mechanism retaining button (fig. 10). Once released, the trigger assembly can be pulled back from the stock assembly.

With the trigger mechanism removed, the magazine can be taken out of the stock by simultaneously guilling down and to the rear (fig. 11).





## ounting The Bayonet



Fig. 12

Begin by sliding the bayonet handle and the bayonet spring over the tang of the spike bayonat. Push downward on the handle until the slot for attaching the bayonet screw in exposed. Hold the beyonet carefully in this position with the muzzle ring facing the muzzle of the rifle (fig. 12) and insert the bayonet pin into its proper slot in the beyonet lug. Tighten the bayonet pin with a screwdriver of proper size. Bayonets are illegal to install except on pre-ban guns. imported before September 1994.



- 2. Handguard and gas clylinder
- J. Piston extension
- 4. Piston return spring
- 5. Front sight
- 6. Front sight sout
- 7. Handguard catch
- 8. Bayonet screw
- 9. Bayonet resembly 19. Hold open latch pur
- 11. Hold open latch spring
- 12. Hold open letch:
- 13. Receiver and burral assembly
- 14. Takedown latch
- 15. Trigger guerd letch.
- 18. Letch pin
- 17. Rear housing
- 18. Bolt carrier
- 19. Balt
- 20. Firing pin reteiner
- 21. Sinna oin
- ZZ. Extractor spring
- 23. Extractor
- 24. Recoil spring
- 25, Spring retainer
- 25. Large spring guide
- 27. Small spring guide
- 28. Stock

- 29. Trigger guard spring
- 30. Magazina
- 31. Magazine follower
- 32. Follower spring
- 33. Hinge pin
- 34. Magazine cover
- 35. Cover latch
- 36. Latch spring and sear spring
- 37. Swar
- 31. Latch stop pin
- 39. Trigger guard
- 49. Disconnector hange pin
- 4). Trigger pin
- 42. Safety catch.
- 41 Salety catch spring
- 44, Triggier
- 45. Safety catch pin
- 48. Trigger bar
- 47. Trigger bar pin
- 41. Trigger spring
- 49. Disconnector
- 50. Rebound disconnector
- 51, Hammer
- 52. Hammer strut pin
- 53. Hammer strut
- 54. Hammer spring
- 55. Cleaning rod

SKS-762 CALIBER 7.62 x 39mm INSTRUCTION MANUAL



Distributed By:

1-817-824-8104 Sau-Sew, con

### afety Guidelines For Proper Operation And Handling Of Your SKS Rifle

1. Understand the operating principle of the firearm and become familiar with its handling characteristics before attempting to use it. 2. Keen the oruzzle of the firearm pointed toward a safe direction at all times. Never point the firearm at anything that you do not intend to shoot. Be especially cautious when leading or unloading your firearm.

3. Keep the firearm unloaded when it's not in use. The select way to store any firearm is to keep the emmunition separate from the tirearm. Store your firearm out of sight of visitors and children. Remember that it is the gun owner's responsibility to prevent children and persons unfamiliar with firearms from gausing access to firearms and ammunition.

4. Be absolutely certain of your target and the backstop before preceding to fire. Take the time to check if you are uncertain of

what's behind your taront.

5. Before loading and firing your firearm, examine the bore to make certain it is unobstructed. Firing a gun with any obstruction in the bore - or even a heavy coating of oil or drops of water - can cause the barrel to rupture upon firing, causing serious injury to the shooter and bystanders.

8. Never rely exclusively on your gun's machanical safety. No guarantee can be made that the firearm will not fire even if the safety level is in the "eafe" position, so exercise good judgement. Always unload the fireerm before negotiating an obstacle.

7. Don't shoot at a hard surface or at water. A bullet may ricoches and travel in unpredictable directions with considerable velocity cauting injury and damage to property.

8. Never handle a firearm without checking to see if it's unloaded. 9. Never transport a loaded firearm. Firearms should always be unloaded before being pleced in a yehicle. A suitable carrying case should be used when transporting the firesem.

10. Always wear shooting plasses and our protestion while shooting.

11. In case of failure to fire, always keep the muzzle pointed in a safe direction and hold the firearm in this position for 30 seconds. After 30 seconds has alapsed, remove the magazine and upon the action slowly and retrieve the cartridge. If the primer indentation appears normal, it should be quickly and safely disposed of. If the indent is very light or misaligned, the firearm should be examined by a qualified guns with and the cause of the mallunction should be corrected before future use.

## arnings and Disclaimers

Firearms can be very dangerous if used carelessly. Please read the warnings and instructions in this manual thoroughly before attempting to use this liveerm. If this firearm is carelessly or improperly handled, socidental discharge could result and cause serious injury, death or damage to property.

ALTERATION WARNING. This firesem was designed to function. properly in its original condition only. Any changes made to this product are specifically contrary to instructions. Please do not leopardize your safety or the safety of others by making modifiestions to your firearm.

DANGER - AMMUNITION WARNING: The correct caliber for the SKS rifle is 7.62 x 39mm Soviet. Never attempt to use ammunition of any other caliber in your gun. Use only nevely manufactured ammunition that is of high quality and in good condition. Never use "remanufactured" or hand-loaded (reloaded) ammunition or emmunition that is faulty, incorrect or nonstandard as both the manufacturer and the importer of this firearm specifically disclaim responsibility for any demage or injury whatsoever occurring in connection with or as the result of the use of such amounition with this firearm. We recommend and sell Sellier & Bellot, it is the Best!

#### nstructions On Disassembly Of The Sks Rifle




the rear and visually inspect the chamber to make certain that the rifle is unloaded. After doing so, depress the magazine follower and pently release the bolt, letting it go completely forward.

Step 1: Pull the bolt handle to

Step 2: Leaving the hammer cocked. engage the safety laver on "safa".

Step 3: Rotate the raceiver cover pondecting pin upward to the vertical position (fig. 1), Pull the pin out as far as possible (fig 2).



Step 5: Remove the recoil bolt carrier (fig. 4).




Step 8: Pull the bolt currier/balt assembly to the rear of the receiver (fig. 5). Ramove the entire assembly.

Fig. 5



Step 7: Use a bullet tip to pry up the piston tube locking lever (fig. 6). Position the lever in a way such that the camming surface located at the front is completely vertical.



Step 8: Carabilly raise the handquard assembly and rock it slowly from side to side until it can be pulled away from the gas block [fig. 7].

Step it: The the handquard assembly and the piston will slide out of the piston tube.


The sequence given above is sufficient to field-strip the rille for cleaning and regular maintenance. No further disassembly is recommended except for repair by a qualified gunsmith.

#### leaning The Rifle

Begin with the rifle field-stripped. Attach the bors brush to the cleaning rod (located undernaath the barrel). Saturate the bore brush with gun solvent and push the brush through the length of the barrel. The cap of the accessory tube can be used to protect the crown of the muzzle from damage during cleaning (fig.8). Repeat the procedure with cloth cleaning patches spaked in solvent. Wrap the patches around the bore cleaner. When the louling has been removed, the bore should be wiped dry of solvent. If you do not intend to fire the rifle soon, run a slightly oiled patch through the bore for preservation.



Fig. 8



The bolt, bolt carrier, piston, recoil spring and receiver cover should be wiped off with a clean cloth. The action parts should be coated with a light film of oil. The gas piston and the gas tube should be left clean and dry. Pouring oil into the receiver indiscriminately is not recommended. The basic SKS rifle cleaning kit consists only of a bore brush, bore cleaner and punch. A gas port reamer is not normally included with the rifle. However, we do recommend that you clean the gas gort and the gas block area regularly. To do so, insert the gas port reamer for a similarly-shaped tool) into the gas port of the rille (fig. 9). Turn it electivise until the louling has been removed.